Product information

PI 3/08/15/2024

Camping Multi-Foam Cleaner



Description

The all-rounder for effective, gentle cleaning of all common materials on the interior and exterior while camping. Effortlessly cleans smooth, painted, or foil-coated surfaces without leaving behind streaks or smudges thanks to the highly effective active formula. Also ideally suited for vertical surfaces and stubborn contaminants thanks to the foam's good adherence.

Properties

- streak-free cleaning with highly effective active foam
- for universal use both indoors and outdoors for camping, e.g. on camping furniture, etc.
- very good compatibility with all common materials
- silicone-free

Technical data

Form	liquid, aerosol
Base	combination of additives, oils and solvents
Color / appearance	brown, clear
Spreading rate (cover)	sheet steel, bright 150-200 m²/l
Propellant	CO2
Odor	characteristic
Viscosity at 40 °C	17 mm²/s

Areas of application

For smooth, painted and foil-coated surfaces made of aluminum, plastic, glass, GFRP, polycarbonate, stainless steel, and rubber on the interior and exterior.

Application

1. Shake well before use.2. Spray the surface to be cleaned from a distance of 20 – 30 cm and briefly allow the foam to act.3. Then wipe off the dissolved dirt and polish with the Microfiber Cloth (part no. 1651). Note: Check for compatibility before use with special coatings! Do not allow to dry and avoid using on hot surfaces! Store protected against frost!

Available pack sizes

300 ml Can aerosol	21812 D

Our information is based on thorough research and may be considered reliable, although not legally binding.

LIQUI MOLY GmbH
Jerg-Wieland-Str. 4
89081 Ulm-Lehr

Phone: +49 (0)731/1420-0
Fax: +49 (0)731/1420-82
e-mail: info@liqui-moly.de

Technical hotline: +49 (0)731/1420-871
www.liqui-moly.com